

The QNAP logo is located in the top-left corner of the page. It consists of the letters "QNAP" in a bold, white, sans-serif font, set against a solid blue square background.

**QNAP**

# **QHora-301W**

## **User Guide**

The background of the page features a complex, abstract geometric pattern of overlapping, semi-transparent white and light gray polygons, creating a sense of depth and movement. This pattern is most prominent in the lower-left and bottom-center areas.

Document Version: 2  
15/09/2021

# Contents

## 1. Preface

About This Guide.....	4
Audience.....	4
Document Conventions.....	4

## 2. Product Overview

About the QHora-301W.....	5
Hardware Specifications.....	5
Software Specifications.....	6
Wireless Specifications.....	7
Package Contents.....	8
Components.....	8
Front Panel.....	9
Rear Panel.....	10
Safety Information.....	11

## 3. Installation and Access

Installation Requirements.....	12
Setting Up the Router.....	12
Connecting the Router to the Internet.....	12
Router Access.....	14
Accessing the Router Using a Browser.....	14
Accessing the Router Using Qfinder Pro.....	15

## 4. QuRouter

About QuRouter.....	16
System Requirements.....	16
Getting Started.....	16
Configuring QuRouter.....	17
Enabling the Full Wireless Functionality in QuRouter.....	19
Binding the Router with a QNAP ID.....	19
Unbinding the Router from a QNAP ID.....	20

## 5. QuRouter Navigation

Taskbar.....	21
Dashboard.....	22

## 6. System Configuration

System.....	24
Configuring Router Operation Modes.....	24
Configuring Access Point (AP) Mode.....	24
Managing Event Logs.....	25
System Settings.....	25
USB Settings.....	28
Firmware.....	29
Checking for Live Updates.....	30
Updating the Firmware Manually.....	30

## 7. Network Settings

Network.....	31
--------------	----

Changing WAN Port Configurations.....	31
Configuring Wide Area Network (WAN) Interface Settings.....	31
Configuring Local Area Network (LAN) Access and Trunk Modes.....	33
VLAN.....	34
Static Route.....	36
Wireless/Virtual Access Points.....	39
Virtual Access Points.....	39
Configuring the Guest Wireless Network.....	41
Wi-Fi Protected Setup (WPS).....	42
Clients.....	43
Adding a Device to the Blocked List.....	43
Configuring a Device in the Blocked List.....	44
Deleting a Device from the Blocked List.....	44
SD-WAN.....	44
About QuWAN.....	45
Configuring QuWAN Settings.....	45
Accessing QuWAN Orchestrator.....	46
QVPN.....	46
QVPN Server Settings.....	46
QVPN Client Settings.....	50
Managing QVPN Logs.....	51
Service Port Management.....	51
Adding a Custom Service Port.....	51
Deleting a Custom Service Port.....	52
DDNS Settings.....	52
Configuring DDNS (My DDNS) Settings.....	53
Modifying the DDNS Domain Name.....	53

## 8. Security Settings

Firewall.....	54
Adding a Firewall Rule.....	54
Configuring a Firewall Rule.....	55
Deleting a Firewall Rule.....	56
Network Address Translation (NAT).....	56
Application Layer Gateway (ALG).....	56
Port Forwarding.....	56
Demilitarized Zone (DMZ).....	57
Discovery Settings.....	58
Configuring Universal Plug and Play (UPnP).....	58
Parental Controls.....	59
Adding a Parental Control Role.....	59
Configuring a Parental Control Role.....	60
Deleting a Parental Control Role.....	60
Adding a Device to a Parental Control Role.....	60
Deleting a Device from a Parental Control Role.....	60
Quality of Service (QoS).....	61
Configuring QoS Settings on QuWAN Orchestrator.....	61

## 9. Support and Other Resources

Support and Other Resources.....	63
----------------------------------	----

## 10. Glossary

myQNAPcloud.....	64
QNAP ID.....	64
Qfinder Pro.....	64
QuRouter.....	64

QuWAN..... 64  
 QuWAN Orchestrator..... 64

**11. Notices**

Limited Warranty..... 65  
 Disclaimer..... 65  
 CE Notice..... 65  
 FCC Notice..... 66  
 Radio Equipment Directive (RED) 2014/53/EU Article 10..... 66  
 EU RoHS statement..... 67  
 ISED Compliance Statement..... 67  
 Radiation Exposure Statement..... 67  
 UKCA Notice..... 67

# 1. Preface





## About This Guide

This guide provides information on the QNAP QHora-301W router and step-by-step instructions on installing the hardware. It also provides instructions on basic operations and troubleshooting information.

## Audience

This document is intended for consumers and network administrators. This guide assumes that the user has a basic understanding of network, storage, and backup concepts.

## Document Conventions

Symbol	Description
	Notes provide default configuration settings and other supplementary information.
	Important notes provide information on required configuration settings and other critical information.
	Tips provide recommendations or alternative methods of performing tasks or configuring settings.
	Warnings provide information that, when ignored, may result in potential loss, injury, or even death.

## 2. Product Overview

This chapter provides basic information about the QNAP device.

### About the QHora-301W

The QHora-301W is QNAP's first 802.11ax-enabled router that comes with dual 10 GbE ports. The router features built-in SD-WAN technology to support VPN deployment. The QHora-301W features eight internal 5dBi antennas, four 1 GbE ports, and supports wireless transfer speeds up to 3600 Mbps. You can deploy the router as a hub or edge using QuWAN, QNAP's software defined-WAN (SD-WAN) technology.

### Hardware Specifications



#### Warning

If your QNAP product has hardware defects, return the product to QNAP or a QNAP-authorized service center for maintenance or replacement. Any attempt to repair or perform maintenance procedures on the product by you or an unauthorized third party invalidates the warranty.

QNAP is not responsible for any damage or data loss caused by unauthorized modifications and installation of unsupported third-party applications.

For details, see the [QNAP Warranty Terms and Conditions](#).



#### Tip

Model specifications are subject to change without prior notice. To see the latest specifications, go to <https://www.qnap.com>.

Component	QHora-301W
Processor	
CPU	Qualcomm® IPQ8074A Hawkeye 2
Frequency	4-core 2.2 GHz
Architecture	ARM Cortex-A53
Memory	1 GB RAM
Flash memory	4 GB eMMC
Network	
Gigabit Ethernet ports	<ul style="list-style-type: none"> <li>• 2 x 10 GbE RJ45</li> <li>• 4 x 1 GbE RJ45</li> </ul>
Antenna	8 x 5dBi internal antennas
Total power consumption	24W
External I/O Ports & Expansion Slots	
USB ports	2 x USB 3.2 Gen 1 Type-A
Interface	
Buttons	<ul style="list-style-type: none"> <li>• Reset</li> <li>• WPS</li> </ul>
Switches	Power
Dimensions	
Dimensions (H x W x D)	250 × 180 × 48 mm (9.84 x 7.08 x 1.88 in)

Component	QHora-301W
Net weight	1.9 kg (4.18 lbs)
Other	
Operating temperature	0°C to 40°C (32°F to 104°F)
Relative humidity	Non-condensing relative humidity: 5% to 95%
Mount support	75 x 75 mm VESA mount (2.95 x 2.95 in)

## Software Specifications

Specification	Description
System Status and Management	<ul style="list-style-type: none"> <li>• Device connection status</li> <li>• Device health status</li> <li>• WAN status</li> <li>• Wireless status</li> <li>• Firmware schedule management</li> </ul>
Wired Network Management	<ul style="list-style-type: none"> <li>• Recommended WAN port configurations and usage scenarios: <ul style="list-style-type: none"> <li>• 1GbE-1 port</li> <li>• 10GbE-1 port</li> <li>• 1GbE-1 and 1GbE-2 ports</li> </ul> </li> <li>• WAN/LAN port configuration</li> <li>• Network port connection status</li> <li>• IEEE 802.3Q virtual LAN (VLAN)</li> <li>• IPv4 address routing management</li> </ul>
Security	<ul style="list-style-type: none"> <li>• Protocol-based firewall (TCP, UDP, ICMP, TCP+UDP)</li> <li>• IP address-based firewall rule configuration</li> <li>• Network Address Management (NAT) and port forwarding</li> </ul>
VPN	<ul style="list-style-type: none"> <li>• Remote access support using L2TP, OpenVPN, and QBelt (QNAP proprietary VPN) protocols</li> <li>• Client IP pool management</li> <li>• VPN client management</li> <li>• Connection logs</li> <li>• Maximum VPN tunnels: 30</li> </ul>
Access Control	<ul style="list-style-type: none"> <li>• Parental control</li> <li>• Domain Name Filtering (DNS) and content filtering</li> </ul>

Specification	Description
System Settings	<ul style="list-style-type: none"> <li>• Backup and restore</li> <li>• Restart, reset</li> <li>• Manage audio alerts</li> <li>• Local account and QNAP ID management</li> <li>• USB settings: USB device user management, USB usage overview, FTP server management</li> </ul>
QuWAN	Configure organization, region, site, device name, and device role

## Wireless Specifications

Specification	Description
Standards	<ul style="list-style-type: none"> <li>• IEEE 802.11ax/ac/n/a 5 GHz</li> <li>• IEEE 802.11n/b/g 2.4 GHz</li> </ul>
Operating Frequency	2.4 GHz, 5 GHz
Speeds	AX3600 <ul style="list-style-type: none"> <li>• 5 GHz (2475 Mbps): 4 x 4 (80 MHz), 2 x 2 (160 MHz)</li> <li>• 2 GHz (1182 Mbps): 4 x 4 (40 MHz)</li> </ul>
Modes	<ul style="list-style-type: none"> <li>• Router mode</li> <li>• Access point (AP) mode</li> </ul>
Guest Wireless Network	<ul style="list-style-type: none"> <li>• 1 x 5 GHz</li> <li>• 1 x 2.4 GHz</li> </ul>
Encryption	<ul style="list-style-type: none"> <li>• WPA (Wireless Protected Access)</li> <li>• WPA2-PSK</li> <li>• WPA-PSK + WPA2-PSK</li> <li>• WPA-Enterprise</li> <li>• WPA2-Enterprise</li> </ul>




Specification	Description
Wireless Network Management	<ul style="list-style-type: none"> <li>• Supports IEEE 802.11ax</li> <li>• Supports MU-MIMO technology</li> <li>• Supports band steering for dual-band (2.4 GHz and 5 GHz band) access points</li> <li>• Transmission power (high, middle, and low)</li> <li>• 20/40/80/160 MHz bandwidth</li> <li>• Auto and custom DFS (Dynamic Frequency Selection) channels</li> <li>• RTS/CTS (Request to Send/Clear to Send) functions</li> <li>• IEEE 802.3Q virtual LAN (VLAN) (Support for wired and wireless interface)</li> <li>• Smart connect</li> <li>• Supports IEEE 802.11r fast roaming</li> <li>• Wireless scheduler</li> <li>• Wireless Protected Setup (WPS)</li> </ul>

## Package Contents

Item	Quantity
QHora-301W router	1
AC power adapter	1
Ethernet cable	1

## Components

## Front Panel



No.	Component	No.	Component
1	Power LED	4	Gigabit Ethernet activity LEDs
2	10 Gigabit Ethernet Activity LEDs	5	Router status
3	Wireless LED	-	-

## LEDs


LEDs indicate the system status and related information when the device is powered on. The following LED information applies only when the drive is correctly installed and when the device is connected to the network or to a host.

For details on the location of the LEDs, see [Components](#).

LED	Status	Description
Power	Green	The device is powered on.
System Status	Flashes green every 0.5 seconds	<ul style="list-style-type: none"> <li>The firmware is being updated.</li> <li>The device is restarting.</li> <li>The device is being initialized.</li> <li>The device is locating another device.</li> </ul>
	Green	The device is ready.
	Red	A system error occurred while powering on the device.

LED	Status	Description
Gigabit Ethernet activity	Green	A network connection has been established.
	Orange	WAN connection has been established.
10 Gigabit Ethernet (RJ45) activity	Green	A network connection has been established.
	Orange	WAN connection has been established.
Wireless	Green	Wireless connection has been established.
	Orange	Press the WPS button for 3 seconds.

## Rear Panel



No.	Component	No.	Component
1	Power input	5	Gigabit Ethernet ports (RJ45)
2	WPS button	6	Reset button
3	USB 3.2 Gen 1 Type-A ports	7	Power switch
4	10 Gigabit Ethernet ports (RJ45)	-	-

## Power Switch

Operation	User Action	Result
Power on	Move the power switch to the on position	The device powers on.
Power off	Move the power switch to the off position	The device powers off.

## Reset Button

QNAP routers can be reset to factory defaults using the reset button located on the rear side of the device.

For details on the component placement, see the rear side of the device (see [Rear Panel](#)).

Operation	User Action	Result
Reset	Press and hold the button for 10 seconds	The router resets and all default settings are restored. This will clear any statically assigned IP address information, WAN and LAN configurations, and security settings. The router is unbound from the QNAP ID.

## Safety Information

The following instructions help ensure personal safety and environmental safety. Read these instructions carefully before performing any operations.

### General Instructions

- The device should be stored in a secure location with restricted access, controlled through the use of a tool, lock and key, or any means of security.
- Only qualified, skilled, and authorized persons with knowledge of all restrictions, safety precautions, and installation and maintenance procedures should have physical access to the device.
- To avoid potential injury or damage to components, ensure that the drives and other internal system components have cooled before touching them.
- Observe electrostatic discharge (ESD) procedures to avoid potential injury or damage to components.

### Power

- To reduce the risk of fire or electric shock, ensure that you only connect the power cord to a properly grounded electrical outlet.



Devices with redundant power supply may have one or more power supply unit (PSU) cords. To avoid serious injuries, a trained service technician must disconnect all PSU cords from the device before installing or replacing system components.

## 3. Installation and Access

This chapter provides specific hardware installation and router access steps.

### Installation Requirements


Category	Item
Environment	<ul style="list-style-type: none"> <li>Room temperature: 0°C to 40°C (32°F to 104°F)</li> <li>Non-condensing relative humidity: 5% to 95%</li> <li>Wet-bulb temperature: 27°C (80.6°F)</li> <li>Flat, anti-static surface without exposure to direct sunlight, liquids, or chemicals</li> </ul>
Hardware and peripherals	Network cable
Tools	Anti-static wrist strap

### Setting Up the Router

- Place your router in an environment that meets the requirements.  
For details, see [Installation Requirements](#).
- Power on the router.  
For details, see [Rear Panel](#).
- Check if the power LED and system status LED are green.  
For details, see [LEDs](#).
- Connect the router to the network and the computer.  
For details, see [Connecting the Router to the Internet](#).
- Check if the WAN interface LED is orange and LAN interface LED is green.  
For details, see [LEDs](#).
- Log on to QuRouter with the local account credentials or QNAP ID.  
For details, see [Binding the Router with a QNAP ID](#).

### Connecting the Router to the Internet

- Connect the power cord to the electrical outlet.
- Power on the router.
- Connect the router to the Internet.
  - Connect the router to WAN interface.
  - Connect an Ethernet cable to the 1 GbE port 1 interface on the router.
  - Connect the Ethernet cable to the Ethernet port of the ISP gateway.



4. Connect the router to the computer.
  - a. Connect an Ethernet cable to any other 1 GbE port on the router.
  - b. Connect the Ethernet cable to a Gigabit Ethernet port on the computer.
5. Verify that the router is recognized by the computer.
  - a. Open Qfinder Pro on the host computer.



**Note**

To download Qfinder Pro, go to <https://www.qnap.com/utilities>.

- b. Locate the router on the list.
6. Open a web browser.
7. Enter <http://192.168.100.1> to access the QuRouter web interface.
8. Follow the installation guide to configure the initial settings of QHora-301W.

## Router Access

Method	Description	Requirements
Web browser	<p>You can access the router using any computer on the same network if you have the following information:</p> <ul style="list-style-type: none"> <li>• Router IP address</li> <li>• Login credentials of a valid user account</li> </ul> <p>For details, see <a href="#">Accessing the Router Using a Browser</a>.</p>	<ul style="list-style-type: none"> <li>• Computer that is connected to the same network as the router</li> <li>• Web browser</li> </ul>
Qfinder Pro	<p>Qfinder Pro is a desktop utility that enables you to locate and access QNAP devices on a specific network. The utility supports Windows, macOS, Linux, and Chrome OS.</p> <p>To download Qfinder Pro, go to <a href="https://www.qnap.com/utilities">https://www.qnap.com/utilities</a>.</p> <p>For details, see <a href="#">Accessing the Router Using Qfinder Pro</a>.</p>	<ul style="list-style-type: none"> <li>• Computer that is connected to the same network as the router</li> <li>• Web browser</li> <li>• Qfinder Pro</li> </ul>

### Accessing the Router Using a Browser

You can access the router using any computer on the network if you know its IP address and the login credentials of a valid user account.



#### Note

If you do not know the IP address of the router, you can locate it using Qfinder Pro.

1. Verify that your computer is connected to the same network as the router.
2. Open a web browser on your computer.
3. Enter the IP address of the router in the address bar.  
The QuRouter web interface page appears.
4. Specify the default username and password.


Default Username	Default Password
admin	<p>QuRouter: The router MAC address without any punctuation and all letters capitalized.</p> <div style="display: flex; align-items: center;"> <div> <p><b>Tip</b> For example, if the MAC address is 00:0a:0b:0c:00:01, the default password is 000A0B0C0001.</p> </div> </div>

5. Click **Login**.  
The QuRouter dashboard page appears.

## Accessing the Router Using Qfinder Pro

Qfinder Pro is a desktop utility that enables you to locate and access QNAP devices on a specific network. The utility supports Windows, macOS, Linux, and Chrome OS.

1. Install Qfinder Pro on a computer that is connected to the same network as the router.  
To download Qfinder Pro, go to <https://www.qnap.com/utilities>.
2. Open Qfinder Pro.  
Qfinder Pro automatically searches for all QNAP devices on the network.
3. Locate the router in the list and then double-click the name or IP address.  
The default web browser page opens.
4. Specify the default username and password.

Default Username	Default Password
admin	QuRouter: The router MAC address without any punctuation and all letters capitalized.   <b>Tip</b> For example, if the MAC address is 00:0a:0b:0c:00:01, the default password is 000A0B0C0001.

5. Click **Login**.  
The QuRouter dashboard page appears.



## 4. QuRouter

### About QuRouter

QuRouter is a centralized management interface that comes with your QNAP router, accessible by visiting the router's IP address in a web browser. With its intuitive interface, QuRouter makes it easy to set up, secure, and configure the features of your router.

### System Requirements

Category	Details
Hardware	A QNAP router
Software	<ul style="list-style-type: none"> <li>• Web browser:               <ul style="list-style-type: none"> <li>• Microsoft Edge 42 or later</li> <li>• Mozilla Firefox 60.0 or later</li> <li>• Apple Safari 11.1 or later</li> <li>• Google Chrome 70.0 or later</li> </ul> </li> <li>• Qfinder Pro 6.9.2 or later</li> </ul>

### Getting Started

1. Log on to QuRouter with the local account credentials or QNAP ID.  
For details, see [Binding the Router with a QNAP ID](#).
2. Configure network settings.  
For details, see [Changing WAN Port Configurations](#).
3. Configure wireless settings.  
For details, see the following topics:
  - [Configuring Virtual Access Point Settings](#)
  - [Configuring the Guest Wireless Network](#)
  - [Configuring Wi-Fi Protected Setup \(WPS\)](#)
4. Configure system settings.  
For details, see the following topics:
  - [Editing the Device Name](#)
  - [Configuring Access Control Settings](#)
  - [Restart, Reset, Backup, and Restore](#)
  - [Configuring Audio Alert Settings](#)
5. Configure QVPN settings.  
For details, see the following topics:
  - [Adding a VPN User](#)

- [Enabling QBelt VPN Server](#)
- [Enabling L2TP VPN Server](#)
- [Enabling OpenVPN VPN Server](#)

## Configuring QuRouter

This sections explains how to configure the router using the web management interface during the initial setup process.

1. Open a web browser.
2. Enter 192.168.100.1 in the address bar.  
The QuRouter login screen appears.
3. Alternatively, use Qfinder Pro to locate the router on the list.
4. Double-click on the name or IP address.  
The **Smart Installation Guide** page appears.
5. Click **Start**.  
The local account password page appears.
6. Specify a new password for the local account.



### Note

The default password is the router MAC address without any punctuation and all letters capitalized.  
For example, if the MAC address is 00:0a:0b:0c:00:01, the default password is 000A0B0C0001.



The MAC address can be found on the asset tag on the bottom of the device.

7. Click **Next**.  
The domain selection page appears.
8. Select the domain from the following.
  - **Global**
  - **China**
9. Click **Next**.  
The **WAN Settings** page appears.
10. Select one of the following WAN interface settings.

Setting	Description
DHCP	Obtain IP address settings automatically via DHCP

Setting	Description
<b>Static IP</b>	Manually assign a static IP address. You must specify the following information: <ul style="list-style-type: none"> <li>• Fixed IP address</li> <li>• Subnet mask</li> <li>• DNS server</li> </ul>
<b>PPPoE</b>	Select this option to specify a username and password for Point-to-Point Protocol over Ethernet (PPPoE).

11. Click **Apply**.
12. Specify the current location of the device.
  - a. Click the drop-down list to select the country or region.




**Note**

If the selected location does not match with the IP geolocation of the device a confirmation message appears prompting you to use the router in basic wireless mode. The basic wireless mode has the following limitations:

- The only channels available are from 1 to 11 in the 2.4 GHz band
- 5 GHz bands are unavailable
- The 2.4 GHz band operates on low output power

- b. Click **Apply**.  
 QuRouter verifies the location of the device.

13. Update the firmware to the latest version.  
 For details, see the [Firmware](#) section.
14. Click **Apply**.
15. Specify the default username and password.


Default Username	Default Password
admin	QuRouter: The router MAC address without any punctuation and all letters capitalized.   <b>Tip</b> For example, if the MAC address is 00:0a:0b:0c:00:01, the default password is 000A0B0C0001. The MAC address can be found on the asset tag on the rear side of the device.

16. Click **Login**.  
 The **Local Account** window appears.
17. Optional: You can log in to QuRouter using your QNAP ID and password.  
 For details, see [Binding the Router with a QNAP ID](#).
18. Reenter or modify the local account username and password.
19. Click **OK**.  
 A confirmation message appears.

QuRouter saves the settings.

## Enabling the Full Wireless Functionality in QuRouter

1. Open QuRouter.
2. Click **Basic Wireless Mode**.



The **Wireless Regulatory Domain Settings** page appears.

3. Select the current location of the device.
4. Click **OK**.

QuRouter enables all the wireless functions of the router.

## Binding the Router with a QNAP ID

1. Open QuRouter.
2. Log in with your QNAP ID and password.




### Note

To create a new QNAP account, click **Create Account**.

3. Click **Login**.  
The **Local Account** window appears.
4. Enter the local account credentials in order to complete the 2-step verification process.
5. Click **OK**.  
The QuRouter dashboard opens and the **Edit Device Name** window appears.
6. Specify a device name containing between 3 to 15 alphanumeric characters.
7. Click **OK**.

The router is bound to the QNAP ID.

## Unbinding the Router from a QNAP ID

1. Log in to QuRouter.
2. Go to **System > Access Control > Administrator** .
3. Below **Unbind QNAP ID**, click  .  
A confirmation message appears.
4. Click **OK**.



### Note

The router is unbound from the QNAP ID and you are logged out of QuRouter.


## 5. QuRouter Navigation

### Taskbar






No.	Element	User Action
1	[USER_NAME]	<b>Logout:</b> Logs the user out of the current session
2	<b>More</b>	Click the button to view the following menu items: <ul style="list-style-type: none"> <li>• <b>Language:</b> Opens a list of supported languages and allows you to change the language of the operating system</li> <li>• <b>About:</b> Displays the following information:                             <ul style="list-style-type: none"> <li>• Operating system</li> <li>• Hardware model</li> <li>• Firmware version</li> </ul> </li> </ul>
3	QuWAN	Click the button to view QuWAN-related information. <ul style="list-style-type: none"> <li>• QuWAN Orchestrator connection status</li> <li>• Organization</li> <li>• QuWAN settings</li> <li>• Link to QuWAN Orchestrator</li> </ul>

## Dashboard



No.	Section	Displayed Information	User Action
1	Overview	<ul style="list-style-type: none"> <li>Uptime (number of days, hours, minutes and seconds)</li> <li>CPU temperature</li> <li>Firmware information</li> </ul>	-
2	Device Connection Status	<ul style="list-style-type: none"> <li>Internet status</li> <li>Device status</li> <li>Number of connected clients</li> </ul>	-
3	WAN Overview	<ul style="list-style-type: none"> <li>Port information</li> <li>WAN interface</li> <li>IPv4 address</li> <li>Global IPv6 address</li> <li>IPv6 link-local address</li> <li>Traffic</li> </ul>	Click <b>WAN Settings</b> to open <b>Network &gt; WAN &amp; LAN Settings</b> .

No.	Section	Displayed Information	User Action
4	Virtual Access Point Groups	Virtual Access Groups/ Guest Wireless Network <ul style="list-style-type: none"> <li>• SSID</li> <li>• Password</li> </ul>	<ul style="list-style-type: none"> <li>• Click <b>Wireless Settings</b> to open the wireless settings page.</li> <li>• Click  to enable a VAP group or guest wireless network.</li> </ul> <p> <b>Tip</b> Click  to make the password visible.</p>



## 6. System Configuration

### System

#### Configuring Router Operation Modes

QuRouter provides access to two router operation modes.


- **Wireless router:** The default router mode where the device can connect to the internet and share the wireless network with its client devices. NAT and DHCP are enabled by default.
- **Access point (AP):** The router connects to a wireless router using a network cable to extend the coverage of the wireless signal to other network devices. Router-related features (DHCP server, NAT, QuWAN, and WAN) are disabled when the router operates as a wireless access point. For details on configuring access point mode, see [Configuring Access Point \(AP\) Mode](#).

1. Go to **System > Operation Mode**.
2. Select a router operation mode.
3. Click **Apply**.

QuRouter applies the operation mode settings.

#### Configuring Access Point (AP) Mode

1. Log in to QuRouter.
2. Go to **System > Operation Mode**.
3. Select **Access point (AP) mode**.
  - a. Optional: Select **Enable Spanning Tree Protocol (STP)**.
  - b. Select one of the following:
    - **DHCP:** Obtains the IP address information automatically from the DHCP server.
    - **Static IP:** Specify the IP address information manually. Configure the following static IP address settings:

Setting	User Action
Fixed IP address	Specify a fixed IP address.   <b>Tip</b> Examine your network setup for guidance on how to best configure these settings.
Subnet mask	Specify the subnet mask used to subdivide your IP address.
Lease time	Specify the length of time that an IP address is reserved for a DHCP client. The IP address is made available to other clients when the lease expires.
Default gateway	Specify the IP address of the default gateway for the DHCP server.
DNS server	Specify a DNS server for the DHCP server.

4. Click **Apply**.  
A confirmation message appears.

5. Click **OK**.



**Important**

The following settings are changed when the router is switched to AP mode.

- The router is unbound from the QNAP ID.
- The router is removed from the QNAP organization and QuWAN. You must reconfigure the QuWAN settings if you enable the router mode again.

6. Run Qfinder Pro on a computer that is connected to the same local area network.



**Note**

To download Qfinder Pro, go to <https://www.qnap.com/utilities>.

7. Locate the router in the list and double-click the name or IP address.  
The login screen appears.

8. Enter the local account credentials of the router.

9. Click **Login**.



**Note**

QuRouter displays only information related to access point settings such as network, wireless, firmware, and system settings.

## Managing Event Logs

You can view a record of event logs related to the router by going to **System > Event Logs** . Common events include enabling or disabling network services, configuring account and system settings, and configuring security settings.



System / Event Logs  
Manage and monitor real-time system events such as event severity, event log date and time, source IPs, event log data export, etc.

Severity Level	Date & Time	Source IP Address	Category	Contents
✘	2020-12-18 10:12:22	127.0.0.1	General	[QuRouter] WAN Port 1 failed to connect to the Internet.
✘	2020-12-18 10:11:21	127.0.0.1	General	[QuRouter] WAN Port 1 failed to connect to the Internet.
ⓘ	2020-12-18 10:11:17	192.168.100.101	General	[QuRouter] User "admin" logged in.
✘	2020-12-18 10:10:45	127.0.0.1	General	[QuRouter] WAN Port 1 failed to connect to the Internet.
ⓘ	2020-12-18 10:10:41	192.168.100.101	General	[QuRouter] User "admin" logged in.
ⓘ	2020-12-18 10:09:12	192.168.100.101	system	[QuRouter] Configured primary device "Office".
ⓘ	2020-12-18 10:08:42	192.168.100.101	Wireless	[QuRouter] Edited the wireless network information. SSID: TWQMIRO1, Connection type: 2.4G/5G-1/5G-2
ⓘ	2020-12-18 10:05:08	192.168.100.101	Firmware Update	[QuRouter] The latest firmware version is available for download. Firmware version: 1.0.6.0001
ⓘ	2020-12-18 10:04:06	127.0.0.1	System	[QuRouter] LAN port "2" connected.
⚠	2020-12-18 10:04:04	127.0.0.1	System	[QuRouter] LAN port "2" disconnected.

Page 1 / 1      Display Item 1-12, Total 12    Show 20 Item(s)

## System Settings

## Editing the Device Name

1. Go to **System > System Settings > Device Name Settings** .
2.  Click  .  
The **Edit Device Name** window appears.
3. Specify device name that consists of 3 to 15 characters from any of the following group:  
Valid characters: A-Z, a-z, 0-9
4. Click **OK**.

QuRouter updates the device name.

## Restart, Reset, Backup, and Restore

QuRouter system settings allows you to remotely control the restart, reset, backup, and restoration operations of the router.

### Restarting the Router

1. Go to **System > System Settings > Restart / Reset / Backup / Restore** .
2. Click **Restart**.  
A confirmation message appears.
3. Click **OK**.

QuRouter restarts the device.

### Resetting the Router

1. Go to **System > System Settings > Restart / Reset / Backup / Restore** .
2. Click **Reset**.  
A confirmation message appears.
3. Click **I agree**.
4. Click **OK**.

QuRouter resets the device to default settings and the router is unbound from QNAP ID.

### Backing Up System Settings

1. Go to **System > System Settings > Restart / Reset / Backup / Restore** .
2. Click **Backup**.

The device exports the system settings as a BIN file and downloads the file to your computer.

### Restoring System Settings





#### Warning

If the selected backup file contains user or user group information that already exists on the device, the system will overwrite the existing information.

1. Go to **System > System Settings > Restart / Reset / Backup / Restore** .
2. Under **Restore**, click **Browse**.  
A file explorer window opens.
3. Select a valid BIN file that contains the device system settings.
4. Click **Restore**.

QuRouter restores the router settings.


### Configuring Audio Alert Settings

1. Go to **System > System Settings > Audio Alert** .
2.  .  
Click  .  
QuRouter enables audio alerts on the router.


### Configuring Access Control Settings



Access Control is a security feature that enforces security policies on devices that can access the router network to increase network security and minimize security threats.

1. Go to **System > Access Control > Access Control Settings** .
2. Enable the access control settings.

Setting	User Action
Local Management via HTTP	Enable to use encrypted browser communication via the Hypertext Transfer Protocol (HTTP).   <b>Note</b> HTTP connections are faster than Hypertext Transfer Protocol Secure (HTTPS); however, the transferred content is not encrypted.
Remote Management	Enable to allow administrators remote access to the router web interface via the WAN IP address.

### Configuring Local Account Settings

 **Note**  
The administrator account is the default router account. You cannot delete the administrator account.

1. Go to **System > Access Control > Administrator** .
2.  .  
Click  to configure local account credentials.  
The **Local Account** window appears.
3. Configure the local account settings.

Description	User Action
Username	Specify a username that contains 5 to 32 characters. Valid characters: A-Z, a-z, 0-9
Current Password	Enter the current password of the local account.
New Password	Specify a password that contains 8 to 64 ASCII characters.
Confirm New Password	Enter the password again.

4. Click **OK**.

QuRouter updates the local account settings.

## USB Settings


The **System > USB Settings** page allows you to access and manage USB-related settings, FTP access, and FTP users.

### Configuring FTP Access

1. Go to **System > USB Settings**.
2. Enable **FTP Server**.

3.  Click . The **FTP Settings** window appears.

4. Configure the FTP server settings.

Setting	User Action
<b>Concurrent Connections</b>	Specify a number between 1 and 9.   <b>Note</b> QuRouter allows up to 9 concurrent connections.
<b>File Name Encoding</b>	Select from the following options:  <ul style="list-style-type: none"> <li>• <b>utf-8</b></li> <li>• <b>big5</b></li> </ul>

5. Click **Save**.  
QuRouter saves the FTP settings.





#### Note

Click the external link IP address to access the contents of the USB device connected to the router if you are accessing the network through the WAN port.  
Click the internal link IP address to access the contents of the USB device connected to the router if you are accessing the network through the LAN port.

### Adding an FTP User

1. Go to **System > USB Settings**.
2. Click **Add FTP User**.  
The **Add FTP User** window appears.



3. Configure the FTP user settings.

Setting	User Action
Username	Enter a username that contains 5 to 32 characters. Valid characters: A-Z, a-z, 0-9
Password	Specify a password that contains 8 to 63 characters.  <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;"></div> <div> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Passwords are case-sensitive.</li> <li>• Click  to make the password visible.</li> </ul> </div> </div>

4. Click **Add**.



QuRouter saves the FTP user information.

### Configuring an FTP User

1. Go to **System > USB Settings**.
2. Identify an FTP user to configure.
3.  Click . The **Edit FTP User** window appears.
4. Configure FTP user settings.  
For details, see [Adding an FTP User](#).
5. Click **Edit**.

QuRouter updates the FTP user information.

### Deleting an FTP User

1. Go to **System > USB Settings**.
2. Identify an FTP user you want to delete.
3.  Click . A confirmation message appears.
4. Click **OK**.

QuRouter deletes the FTP user.

### Firmware

QNAP recommends keeping your router firmware up to date. This ensures that your router can benefit from new features, enhancements, and bug fixes.

## Checking for Live Updates

1. Go to **Firmware**.
2. Enable **Live update**.
3. Select one or more of the following options:
  - **Update now**
  - **Schedule update at**



### Note

Select the date and time to schedule the firmware update.

4. Click **Apply**.  
A confirmation message appears.
5. Click **Apply**.

QuRouter checks for firmware updates.

## Updating the Firmware Manually

The update may require several minutes or longer, depending on your hardware configuration and network connection.

1. Download the router firmware.
2. Go to <http://www.qnap.com/download>.
  - a. Select your router model.
  - b. Read the release notes and confirm the following:
    - The router model matches the firmware version.
    - Updating the firmware is necessary.
  - c. Ensure that the product model and firmware are correct.
  - d. Download the firmware package.
  - e. Extract the firmware package file.
3. Go to **Firmware**.
4. Select **Manual update**.
5. Click **Browse** and then select the extracted firmware package file.
6. Click **Apply**.

The device is immediately restarted.

## 7. Network Settings

### Network

#### Changing WAN Port Configurations

1. Open QuRouter.
2. Go to **Network > WAN & LAN Settings** .
3. Select the WAN port configuration from the following options based on your network requirements.

Setting	User Action
<b>WAN 1 GbE port 1</b>	Select to build a high-speed 10 GbE intranet by connecting 2 x 10 GbE ports to 10 GbE devices in a LAN environment and connecting the 1 GbE port 1 interface to the WAN interface.
<b>WAN 10 GbE port 1</b>	Select to configure a high-speed interoffice VPN network by connecting the 10 GbE port 1 interface to the WAN interface and connecting the 10 GbE port 2 interface to a server or storage device in a LAN environment.
<b>WAN 1 GbE port 1 and 1 GbE port 2</b>	Select to configure an SD-WAN environment (QuWAN) by connecting 2 x 1 GbE ports to the WAN interface and connecting 2 x 10 GbE ports to server or storage devices in a LAN environment.

A confirmation message appears.

4. Click **Apply**.





#### Important

Updating the WAN port configuration automatically deletes all the port forwarding rules.

QuRouter updates the WAN port configuration.

#### Configuring Wide Area Network (WAN) Interface Settings


1. Open QuRouter
2. Go to **Network > WAN & LAN Settings** .
3. Identify a WAN interface.
4.  Click  .  
The port configuration window appears.
5. Configure the IPv4 settings.
  - a. Select the WAN interface setting from the following options.

Setting	Description
<b>DHCP</b>	Obtain IP address settings automatically via DHCP



Setting	Description
<b>Static IP</b>	Manually assign a static IP address. You must specify the following information: <ul style="list-style-type: none"> <li>• Fixed IP Address</li> <li>• Subnet Mask</li> <li>• Default Gateway</li> <li>• DNS Server</li> </ul>
<b>PPPoE</b>	Select to specify a username and password for Point-to-Point Protocol over Ethernet (PPPoE).

b. Configure the DNS settings.

Setting	Description
DNS server	Select from the following: <ul style="list-style-type: none"> <li>• <b>Auto:</b> Automatically obtain the IP address using DHCP.</li> <li>• <b>Manually:</b> Manually assign the IP address for the primary and secondary DNS servers.</li> </ul> <div style="display: flex; align-items: center;">  <p><b>Important</b> QNAP recommends specifying at least one DNS server to allow URL lookups.</p> </div>

c. Specify a port description.

d. Specify an MTU value between 98 and 9000.

e. Specify the transferring and receiving ISP line rate.




**Note**




You can set the ISP line rate only if you have configured the QuWAN and QoS settings.

6. Configure the IPv6 settings.

a. Click **IPv6**.

b. Select the WAN interface.

Setting	User Action
<b>DHCPv6</b>	The adapter automatically acquires an IPv6 address and DNS settings from the DHCPv6-enabled server. <div style="display: flex; align-items: center;">  <p><b>Important</b> This option requires an available DHCPv6-enabled server on the network.</p> </div>

Setting	User Action
<b>Static IP</b>	<p>Manually assign a static IP address to the adapter. You must specify the following information:</p> <ul style="list-style-type: none"> <li>• Fixed IP Address</li> <li>• Prefix length</li> </ul> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <div> <p><b>Tip</b></p> <p>Obtain the prefix length information from your network administrator.</p> </div> </div> <ul style="list-style-type: none"> <li>• Default Gateway</li> <li>• Primary and secondary DNS servers</li> </ul>
<b>PPPoEv6</b>	<p>Select to specify a username and password for Point-to-Point Protocol over Ethernet (PPPoE) IPv6 protocol.</p> <div style="display: flex; align-items: center; margin-top: 10px;">  <div> <p><b>Important</b></p> <p>You must change the IPv4 WAN interface to PPPoE if you want to use PPPoEv6 as the WAN interface.</p> </div> </div>
<b>Stateless (SLAAC)</b>	<p>The adapter automatically acquires an IPv6 address and DNS settings from the router.</p> <div style="display: flex; align-items: center; margin-top: 10px;">  <div> <p><b>Important</b></p> <p>This option requires an available IPv6 RA (router advertisement)-enabled router on the network.</p> </div> </div>

c. Configure the DNS settings.



7. Click **Apply**.


QuRouter updates the WAN settings.

## Configuring Local Area Network (LAN) Access and Trunk Modes

Access mode is used in environments without any user-configured VLANs. This mode allows the router to carry traffic without VLAN tagging and is used to connect end-user devices such as laptops, NAS, or printers.

Trunk mode is used in a VLAN-configured environment and is designed for connecting devices operating on tagged VLANs (for example, VLAN-enabled switch, VLAN-enabled NIC, etc.). Ports using Trunk mode can be linked between various network devices and are capable of carrying traffic across multiple VLANs. A VLAN must be configured prior to configuring Trunk mode on the LAN port.

1. Open QuRouter.
2. Go to **Network > WAN & LAN Settings** .
3. Identify a LAN port.
4.  Under Action, click  . The port configuration window appears.
5. Configure the mode settings.

Setting	User Action
<b>Mode</b>	Select from the following options: <ul style="list-style-type: none"> <li>• <b>Access mode</b></li> <li>• <b>Trunk mode:</b> Select one or more VLANs from the VLAN list to enable trunk mode.</li> </ul>  <b>Tip</b> To create a new VLAN, see <a href="#">Adding a VLAN</a> .
<b>Description</b>	Enter a description for the port.

6. Click **OK**.

QuRouter updates the LAN port mode.

## VLAN


A virtual LAN (VLAN) groups multiple network devices together and limits the broadcast domain. Members of a VLAN are isolated and network traffic is only sent between the group members. You can use VLANs to increase security and flexibility while also decreasing network latency and load.

The VLAN screen displays information about existing VLANs and provides access to VLAN configuration options.

### Adding a VLAN

1. Open QuRouter.
2. Go to **Network > VLAN & DHCP Server Service Settings**.
3. Click **Add VLAN**.  
The **Add VLAN** window opens.
4. Configure the IPv4 VLAN settings.
  - a. Specify a VLAN ID.
  - b. Specify a VLAN description that contains a maximum of 256 characters.
  - c. Specify a fixed IP address.
  - d. Specify the subnet mask.
  - e. Specify an MTU value.
  - f. Select **Enable Spanning Tree Protocol (STP)** to prevent bridge loops.
  - g. Select **Enable DHCP server service**.  
Configure DHCP settings.

Field	Description
<b>Start IP Address</b>	Specify the starting IP address in a range allocated to DHCP clients.
<b>End IP Address</b>	Specify the ending IP addresses in a range allocated to DHCP clients.
<b>Lease Time</b>	Specify the length of time that an IP address is reserved for a DHCP client. The IP address is made available to other clients when the lease expires.

Field	Description
DNS Server	Specify a DNS server for the DHCP server.
Reserved IP Table	<ol style="list-style-type: none"> <li>Click <b>Add</b> to configure a reserved IP table.</li> <li>Specify the following: <ul style="list-style-type: none"> <li>Device name</li> <li>IP address</li> <li>MAC address</li> </ul> </li> <li>Click  .</li> </ol>

5. Configure the IPv6 VLAN settings.

- Click **IPv6**.
- Click **Enable IPv6 VLAN**.
- Select the outgoing WAN interface from the drop-down list.
- Specify the IPv6 IP address prefix.
- Select the prefix length from the drop-down list.
- Select the interface identifier to identify interfaces on a link.

Setting	User Action
Interface identifier	Select from the following: <ul style="list-style-type: none"> <li><b>EUI-64:</b> Select Extended Unique Identifier (EUI-64) to automatically configure IPv6 host address.</li> <li><b>Manually:</b> Specify an interface ID to configure the IPv6 host address.</li> </ul>



- Assign a client IPv6 addressing mode from the drop-down list.

Setting	Description
IPv6 addressing mode	Select from the following: <ul style="list-style-type: none"> <li><b>Stateful:</b> The stateful DHCPv6 or managed mode enables you to manually assign a unique IPv6 address to each client.</li> <li><b>Stateless:</b> The stateless DHCPv6 mode enables users to manually enter additional IPv6 information including the lease time, but automatically assigns a unique IPv6 address to each client.</li> <li><b>SLAAC+RDNSS:</b> Stateless Address Auto-Configuration (SLAAC) along with Recursive DNS Server (RDNS) enables users to manually assign an IP address based on the IPv6 prefix and uses recursive queries to resolve the domain name.</li> <li><b>Disabled:</b> Disables IPv6 client addressing.</li> </ul>

6. Click **Apply**.

QuRouter adds the VLAN.

## Configuring VLAN Settings

1. Open QuRouter.
2. Go to **Network > VLAN & DHCP Server Service Settings** .
3. Identify a VLAN to configure.
4.  .  
Click  .  
The **VLAN Configuration** window opens.
5. Edit the VLAN settings.





### Note

To configure the VLAN settings, see [Adding a VLAN](#).

6. Click **Apply**.

QuRouter updates the VLAN settings.

## Deleting a VLAN

1. Open QuRouter.
2. Go to **Network > VLAN & DHCP Server Service Settings** .
3. Identify the VLAN.
4.  .  
Click  .



### Note

You cannot delete the VLAN if it being utilized by a WAN or LAN port.

A confirmation message appears.

5. Click **Delete**.

QuRouter deletes the VLAN.


## Static Route

You can create and manage static routes in the **Static Route** section of network settings. Under normal circumstances, QuRouter automatically obtains routing information after it has been configured for internet access. Static routes are only required in special circumstances, such as having multiple IP subnets located on your network.

### Adding an IPv4 Static Route

1. Open QuRouter.
2. Go to **Network > Routing > IPv4 / Static Route** .
3. Click **Add Static Route**.  
The **Add Static Route** window appears.

4. Configure the settings.


Setting	User Action
<b>Destination</b>	Specify a static IP address where connections are routed to.
<b>Subnet Mask</b>	Specify the IP address of the destination's subnet mask.
<b>Next Hop</b>	Select from the following next hop options: <ul style="list-style-type: none"> <li>• <b>WAN Port:</b> Select an available WAN port IP address for the routing path.</li> <li>• <b>IP Address:</b> Specify the IP address of the closest or most optimal router in the routing path.</li> </ul>
<b>Metric</b>	Specify the number of nodes that the route will pass through. <div style="border-left: 2px solid #0070C0; padding-left: 10px; margin-top: 10px;">  <b>Note</b>                          Metrics are cost values used by routers to determine the best path to a destination network.                     </div>
<b>Description</b>	Enter a description for the static route.

5. Click **Apply**.

QuRouter creates the IPv4 static route.

### Adding an IPv6 Static Route



1. Open QuRouter.
2. Go to **Network > Routing > IPv6 / Static Route**.
3. Click **Add Static Route**.  
The **Add Static Route** window appears.
4. Configure the settings.

Setting	User Action
<b>Destination</b>	Specify a static IP address where connections are routed to.
<b>Prefix length</b>	Select the prefix length for IPv6 addressing.
<b>Next Hop</b>	Select from the following next hop options: <ul style="list-style-type: none"> <li>• <b>WAN Port:</b> Select an available WAN port IP address for the routing path.</li> <li>• <b>VLAN / Access mode:</b> Select a preconfigured access mode VLAN ID.</li> </ul>
<b>Metric</b>	Specify the number of nodes that the route will pass through. <div style="border-left: 2px solid #0070C0; padding-left: 10px; margin-top: 10px;">  <b>Note</b>                          Metrics are cost values used by routers to determine the best path to a destination network.                     </div>
<b>Description</b>	Enter a description for the static route.

5. Click **Apply**.



QuRouter creates the IPv6 static route.

## Configuring a Static Route

1. Open QuRouter.
2. Select a static route.
  - IPv4 static route: **Network > Routing > IPv4 / Static Route**
  - IPv6 static route: **Network > Routing > IPv6 / Static Route**
3. Identify a static route.
4.  Click  .  
The **Edit Static Route** window appears.
5. Configure the static route settings.  
For details, see the following:
  - [Adding an IPv4 Static Route](#)
  - [Adding an IPv6 Static Route](#)
6. Click **Apply**.

QuRouter updates the static route settings.

## Deleting a Static Route

1. Open QuRouter.
2. Select a static route.
  - IPv4 static route: **Network > Routing > IPv4 / Static Route**
  - IPv6 static route: **Network > Routing > IPv6 / Static Route**
3. Identify a static route.
4.  Click  .  
A confirmation message appears.
5. Click **Apply**.

QuRouter deletes the static route.

## Viewing Routing Table Information

Select a method for viewing routing information.

- IPv4 routing information: **Network > Routing > IPv4 / Routing Table**
- IPv6 routing information: **Network > Routing > IPv6 / Routing Table**

Routing tables provide status information regarding configured route entries from the following sources:


- Directly connected networks

- Dynamic routing protocols
- Statically configured routes

## Wireless/Virtual Access Points

### Virtual Access Points

You can configure multiple virtual access groups from a single physical access point using virtual access points (APs). Each virtual AP group can be configured to control access to wireless devices and implement security protocols. This section controls the virtual AP settings, including Smart Connect, wireless scheduler, and security protocols.



### Configuring Virtual Access Point Settings

1. Go to **Wireless/Virtual Access Point > Wireless**.
2. Identify a virtual AP group to configure.
3. Optional: Enable **Smart Connect** to operate the access point using both 2.4 GHz and 5 GHz wireless bands.



#### Note

When enabled, Smart Connect uses the same SSID and password for both 2.4 GHz and 5 GHz bands.






4.



Click . The **VAP Configuration** window appears.

5. Configure the virtual AP group settings.



Setting	User Action
<b>VLAN ID</b>	Select a VLAN ID from the drop-down list.   <b>Note</b> To configure a new VLAN, go to <a href="#">Adding a VLAN</a> .
<b>SSID</b>	Specify the virtual AP SSID.
<b>Security</b>	Select one of the following security authentication methods: <ul style="list-style-type: none"> <li>• <b>WPA2-PSK</b></li> <li>• <b>WPA-PSK / WPA2-PSK</b></li> <li>• <b>WPA-Enterprise</b></li> <li>• <b>WPA2-Enterprise</b></li> </ul>  <b>Note</b> Enter a Remote Authentication Dial-In User Service (RADIUS) server IP address and server port number if the security authentication method is set to WPA-Enterprise or WPA2-Enterprise. <ul style="list-style-type: none"> <li>• <b>WPA2-PSK / WPA3-Personal</b></li> <li>• <b>OWE</b></li> </ul>
<b>Password</b>	Specify a password between 8 and 63 characters.   <b>Note</b> The password is case-sensitive.   <b>Tip</b> Click  to make the password visible.
<b>Enable 802.11r Fast Roaming</b>	Select to enable the IEEE 802.11r or Fast BSS Transition (FT) to allow a wireless device to roam quickly in a network by pre-authenticating the device.
<b>Enable Wireless Scheduler</b>	You can select specific days and time periods to enable the virtual AP group.




6. Click **Apply**.

QuRouter updates the virtual AP group settings.

### Configuring Advanced Band Settings on Virtual AP Groups

1. Go to **Wireless/Virtual Access Point > Wireless** .
2. Click **Advanced Band Settings**.  
The **Advanced Band Settings** window appears.
3. Configure the advanced settings for 5 GHz or 2.4 GHz bands.

Setting	User Action
<b>Enable Band Steering</b>	Enable to automatically reroute the wireless client to a wireless network that is utilizing the best frequency band available.


Setting	User Action
<b>Enable MU-MIMO</b>	Enable multiple-input, multiple-output technology (MU-MIMO) to allow the router to communicate concurrently with multiple wireless devices.
<b>Transmission Power</b>	Select one of the MU-MIMO transmission powers: <ul style="list-style-type: none"> <li>• <b>High</b></li> <li>• <b>Medium</b></li> <li>• <b>Low</b></li> </ul>
<b>Bandwidth</b>	Specify one of the following frequencies: <ul style="list-style-type: none"> <li>• <b>20 MHz</b></li> <li>• <b>20/40 MHz</b></li> <li>• <b>20/40/80 MHz</b></li> <li>• <b>20/40/80/160 MHz</b></li> </ul> <div style="border-left: 2px solid red; padding-left: 10px; margin-top: 10px;">  <b>Important</b>  <b>20/40/80/160 MHz</b> is available only for the 5 GHz band.         </div>
<b>Enable DFS Channels</b>	Enable Dynamic Frequency Selection (DFS) to utilize more channels and avoid wireless interference. <div style="border-left: 2px solid red; padding-left: 10px; margin-top: 10px;">  <b>Important</b>              This setting is available only for the 5 GHz band.           </div>
<b>Channels</b>	Select the DFS channel that is less frequently used. <div style="border-left: 2px solid blue; padding-left: 10px; margin-top: 10px;">  <b>Note</b>              The channel is set to <b>Auto</b> by default to avoid radio frequency interference.           </div>
<b>Enable CTS/RTS</b>	Specify a CTS/RTS value between 1 and 2347.





4. Click **Apply**.

QuRouter updates the advanced band settings.

### Configuring the Guest Wireless Network

1. Go to **Wireless/Virtual Access Point > Guest Wireless Network**.
2. Select **Enable**.
3. Configure the guest wireless network settings.

Setting	User Action
SSID	Specify a service set identifier (SSID) that can contain up to 32 characters. <div style="border-left: 2px solid blue; padding-left: 10px; margin-top: 10px;">  <b>Note</b>              The SSID is case-sensitive.           </div>


Setting	User Action
Security	<p>Select one of the following security authentication methods:</p> <ul style="list-style-type: none"> <li>• <b>WPA2-PSK</b></li> <li>• <b>WPA-PSK / WPA2-PSK</b></li> <li>• <b>WPA-Enterprise</b></li> <li>• <b>WPA2-Enterprise</b></li> </ul> <p> <b>Note</b> Enter a Remote Authentication Dial-In User Service (RADIUS) server IP address and server port number if the security authentication method is set to WPA-Enterprise or WPA2-Enterprise.</p> <ul style="list-style-type: none"> <li>• <b>WPA2-PSK / WPA3-Personal</b></li> <li>• <b>OWE</b></li> </ul>
Password	<p>Specify a password that contains 8 to 63 characters.</p> <p> <b>Note</b> The password is case-sensitive.</p> <p> <b>Tip</b> Click  to make the password visible.</p>

4. Click **Apply**.


QuRouter saves the guest wireless network settings.

### Wi-Fi Protected Setup (WPS)


The WPS protocol is a standard that helps you easily set up a wireless network without needing to configure wireless network names (SSID) or security specifications.



## Configuring Wi-Fi Protected Setup (WPS)

1. Go to **Wireless/ Virtual Access Point > WPS** .
2. Click  .  
QuRouter enables the WPS function.
3. Configure the WPS settings.

Option	Description
WPS SSID	Select the SSID from the drop-down menu.
<b>WPS</b>	Click <b>WPS</b> to enable WPS on the router. You can press the physical WPS button located on the rear panel of the router.

 **Note**  
For details, see [Rear Panel](#)


## Clients

This section provides access to any wired or wireless clients connected to the router network.

Additionally, you can use the Blocked list to control the management of any clients blocked from accessing wired or wireless services.

### Adding a Device to the Blocked List

1. Go to **Clients > Blocked List** .
2. Click **Block client**.  
The **Add Device to Blocked List** window appears.
3. Configure the settings.

Setting	User Action
Description	Specify the device description.   <b>Note</b> <ul style="list-style-type: none"> <li>• The description must be between 1 to 20 characters.</li> <li>• Valid characters: A-Z, a-z, 0-9</li> <li>• Valid special characters: Hyphen (-), Underscore (_), Period (.)</li> </ul>
MAC Address	Specify the MAC address of the device.

4. Select the interface.

5. Click **Apply**.

QuRouter adds the device to the blocked list.

### Configuring a Device in the Blocked List

1. Go to **Clients > Blocked List** .

2. Identity a device.

3.  .  
Click **Edit Blocked List Device** .  
The **Edit Blocked List Device** window appears.

4. Configure the device settings.  
For details, see [Adding a Device to the Blocked List](#).


5. Click **Apply**.

QuRouter updates the device information.

### Deleting a Device from the Blocked List

1. Go to **Clients > Blocked List** .

2. Identity a device.

3.  .  
Click **Delete** .  
A confirmation message appears.

4. Click **Apply**.

QuRouter deletes the device from the blocked list.

## SD-WAN

## About QuWAN

QuWAN is a QNAP cloud-based SD-WAN networking solution that provides a centralized control platform to manage network functions of devices within its private network topology. QuWAN can intelligently and securely direct traffic across the WAN network.

You can configure the SD-WAN settings on the router and access QuWAN Orchestrator to manage the SD-WAN overlay network.

## Configuring QuWAN Settings



1. Log in to QuRouter.



### Note

If you are logging in with your QNAP ID for the first time, you are prompted to enter the local account credentials as part of the 2-step verification process.

2. Go to **QuWAN > QuWAN Settings**.
3. Configure the QuWAN settings.

Setting	User Action
Organization	<p>Select an organization associated with your QNAP ID.</p> <div style="border-left: 2px solid #0070C0; padding-left: 10px; margin-top: 10px;">  <p><b>Note</b> If there are no organizations associated with your QNAP ID, click <b>Create or edit organization</b>. QuRouter redirects you to QNAP Account website where you can create a new organization or edit an existing one.</p> </div>
Region	<p>Select a region linked with the selected organization. Click <b>Add Region</b> to create a new region.</p>
Site	<p>Select a site from the drop-down menu.</p> <div style="border-left: 2px solid #0070C0; padding-left: 10px; margin-top: 10px;">  <p><b>Note</b> Click <b>Create or edit site</b> to create a new site associated with the selected organization or edit an existing site.</p> </div>
Device Role	<p>Select one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Hub</b>: Configure the device as an SD-WAN hub. A public IP address is required for the WAN connection to select the device as a hub.</li> <li>• <b>Edge</b>: Configure the device as an SD-WAN edge.</li> </ul>
Location	<p>Select one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Locate by IP address</b></li> <li>• <b>Update by GPS coordinates</b></li> </ul>

4. Click **Join the Organization and QuWAN**.



### Important

- The router is unbound from the QNAP ID once it is part of the QuWAN topology.

- The router can support a maximum of 30 VPN tunnels.

A confirmation message appears.


5. Click **OK**.

QuRouter adds the router to the QuWAN topology.

## Accessing QuWAN Orchestrator

1. Open QuRouter.



Click  located on the taskbar.

3. Click **Go to QuWAN Orchestrator**.  
QuWAN Orchestrator opens in a new browser tab.

## QVPN

QVPN settings allow you to create and manage VPN servers, add VPN clients, and monitor VPN logs.


### QVPN Server Settings

QuRouter enables you to configure QNAP routers as a VPN server. You can configure multiple virtual servers to host and deliver VPN services to users in an organization.

### Enabling QBelt VPN Server





QBelt is QNAP's proprietary communications protocol that incorporates Datagram Transfer Layer Security (DTLS) protocol and AES-256 encryption.

1. Open QuRouter.
2. Go to **QVPN Servers > QVPN Settings**.

3. Under QBelt, click  .

4.  .  
Click  .  
The **QVPN Settings** window appears.

5. Configure the QBelt server settings.


Setting	Description
<b>Client IP pool</b>	<p>Specify a range of IP addresses available to connected VPN clients.</p> <p> <b>Important</b> By default, this server reserves the use of IP addresses between 198.18.2.2 and 198.18.2.254. If another connection is configured to use this range, an IP conflict error will occur. Before adding this server, ensure a VPN client isn't configured to use this range as well.</p>
<b>Service Port (UDP)</b>	<p>Select the port used to access the server.</p> <p> <b>Note</b> Default port number: 4433</p>
<b>Pre-shared key</b>	<p>Specify a pre-shared key (password) to verify connecting VPN clients.</p> <p> <b>Tip</b> Pre-shared key requirements:</p> <ul style="list-style-type: none"> <li>• Length: 8-16 ASCII characters</li> <li>• Valid characters: A-Z, a-z, 0-9</li> </ul>
<b>DNS</b>	<p>Specify a DNS server for the QBelt server.</p> <p> <b>Note</b> The DNS server limitation is 1 by default.</p>

6. Click **Apply**.

QuRouter saves the QBelt server settings.

### Enabling L2TP VPN Server

1. Open QuRouter.
2. Go to **QVPN Servers > QVPN Settings** .

3. Under L2TP, click  .






**Important**

You cannot enable the L2TP server if the router is using the QuWAN service. To enable the L2TP server, go to **QuWAN > QuWAN Settings** and click **Leave the organization and QuWAN**.

4.  .  
Click  .  
The **QVPN Settings** window appears.

5. Configure the L2TP server settings.








Setting	Description
<b>Client IP pool</b>	<p>Specify a range of IP addresses available to connected VPN clients.</p> <p> <b>Important</b> By default, this server reserves the use of IP addresses between 198.18.3.2 and 198.18.3.254. If another connection is configured to use this range, an IP conflict error will occur. Before adding this server, ensure a VPN client isn't configured to use this range as well.</p>
<b>Authentication</b>	<p>Select one of the following authentication methods:</p> <ul style="list-style-type: none"> <li>• <b>PAP</b></li> <li>• <b>MS-CHAPv2</b></li> </ul>
<b>Pre-shared key</b>	<p>Specify a pre-shared key (password) to verify connecting VPN clients.</p> <p> <b>Tip</b> Pre-shared key requirements:</p> <ul style="list-style-type: none"> <li>• Length: 8–16 ASCII characters</li> <li>• Valid characters: A–Z, a–z, 0–9</li> </ul>
<b>DNS</b>	<p>Specify a DNS server for the L2TP server.</p> <p> <b>Note</b> The DNS server limitation is 1 by default.</p>

6. Click **Apply**.

QuRouter saves the L2TP server settings.

### Enabling OpenVPN VPN Server

1. Open QuRouter.
2. Go to **QVPN Servers > QVPN Settings** .
3. Under OpenVPN, Click  .
4. Click  .  
The **QVPN Settings** window appears.
5. Configure the OpenVPN server settings.

Setting	Description
<b>Client IP pool</b>	<p>Specify a range of IP addresses available to connected VPN clients.</p> <p> <b>Important</b> By default, this server reserves the use of IP addresses between 198.18.4.2 and 198.18.4.254. If another connection is configured to use this range, an IP conflict error will occur. Before adding this server, ensure a VPN client isn't configured to use this range as well.</p>
<b>Service Port</b>	<p>Select from the following options:</p> <ul style="list-style-type: none"> <li>• <b>TCP</b></li> <li>• <b>UDP</b></li> </ul> <p> <b>Note</b> Default port number: 1194</p>
<b>Encryption</b>	<p>Select from the following encryption methods:</p> <ul style="list-style-type: none"> <li>• <b>Medium (AES 128-bit)</b></li> <li>• <b>High (AES 256-bit)</b></li> </ul>
<b>DNS</b>	<p>Specify a DNS server for the OpenVPN server.</p> <p> <b>Note</b> The DNS server limitation is 1 by default.</p>

6. Enable **Use this connection as a default gateway for remote devices**.



**Note**

Enable to allow the default network gateway to be redirected across the OpenVPN server. All non-local traffic from the client is transferred through the VPN server.


7. Enable **Enable compressed VPN link**.



**Note**

This setting compresses data before transferring it over the VPN. This will increase data transfer speeds, but requires additional CPU resources.

8. Click **Apply**.  
QuRouter saves the OpenVPN server settings.

9. Optional: Click  to download configuration files to set up an OpenVPN server manually.

### Adding a VPN User

1. Open QuRouter.
2. Go to **QVPN Servers > QVPN User Management**.
3. Click **Add**.
4. Specify the username and password.



**Tip**

Specify a password between 8 and 16 characters, containing at least one letter (A-Z, a-z) and one number (0-9).

5. Click **Apply**.

QuRouter adds the VPN user.

## QVPN Client Settings

The QVPN client allows the router to remotely connect to VPN servers using the OpenVPN protocol.




**Important**

- When adding an OpenVPN connection, an OpenVPN configuration file is required to establish the connection.
- To enable QVPN client service, ensure to disable QVPN server service and QuWAN service.

## Creating an OpenVPN Connection Profile


1. Open QuRouter.
2. Go to **QVPN Clients > QVPN Connection Profiles**.
3. Click **Add Profile**.  
The **Create an OpenVPN Connection** window appears.
4. Configure the OpenVPN connection profile.

Setting	User Action
<b>OpenVPN connection profile</b>	Add an OpenVPN configuration file.  <ol style="list-style-type: none"> <li>a. Click <b>Browse</b>. A File Explorer window opens.</li> <li>b. Locate the OpenVPN configuration file.</li> <li>c. Click <b>Open</b>.</li> </ol>
<b>OpenVPN connection profile name</b>	Specify a name to help identify this profile.
<b>Username</b>	Specify the username to access the VPN server.
<b>Password</b>	Specify a password to access the VPN server.   <p><b>Tip</b> Password requirements:</p> <ul style="list-style-type: none"> <li>• Length: 1-64 ASCII characters</li> <li>• Valid characters: A-Z, a-z, 0-9</li> </ul>

5. Select **Automatically reconnect to OpenVPN after restarting the server**.
6. Click **OK**.


QuRouter adds the QVPN connection profile.

## Enabling the QVPN Client Service

1. Open QuRouter.
2. Go to **QVPN Clients > QVPN Connection Profiles** .
3. Select an active profile.
4.  .  
Click .

QuRouter enables the QVPN client service.

## Deleting a QVPN Connection Profile

1. Go to **QVPN Clients > QVPN Connection Profiles** .
2. Identify a connection profile.
3.  .  
Click .  
A confirmation message appears.
4. Click **Yes**.

QuRouter deletes the QVPN connection profile.



### Note

Deleting an active QVPN connection profile automatically disables the QVPN client service.

## Managing QVPN Logs

QuRouter records actions performed by QVPN servers and clients. Recorded information includes connection dates, connection duration, client names, source IP addresses, and protocol information.

Option	UI Path
QVPN server logs	<b>QVPN Servers &gt; Logs</b> .
QVPN client logs	<b>QVPN Clients &gt; QVPN Connection Logs</b> .

1. To clear QVPN logs, click **Clear Logs**.  
A confirmation message appears.
2. Click **Yes**.

QuRouter clears the QVPN logs.


## Service Port Management

The **Service Port Management** feature allows you to easily manage any custom network service ports on your router. You can add customized services for communication with external applications or devices.

## Adding a Custom Service Port

1. Open QuRouter.



2. Go to **Service Port Management**.
3. Click **Add Custom Service**.  
The **Add Custom Service** window appears.
4. Specify the custom service information.

Setting	User Action
<b>Service name</b>	Specify a name for the service.
<b>Protocol</b>	Select from the following network transport protocol: <ul style="list-style-type: none"> <li>• <b>All (TCP+UDP)</b></li> <li>• <b>TCP</b></li> <li>• <b>UDP</b></li> <li>• <b>ESP</b></li> </ul>
<b>WAN service port</b>	Specify a port number. <div style="border-left: 2px solid #ffc107; padding-left: 10px; margin-top: 10px;"> <p> <b>Tip</b></p> <ul style="list-style-type: none"> <li>• Ports must be between 1 - 65535</li> <li>• This field can have up to 15 ports.</li> <li>• Separate multiple ports with commas (,)</li> <li>• Use hyphens (-) without a space to indicate a port range</li> </ul> </div>
<b>Description</b>	Add a description for the custom service.

5. Click **Save**.

QuRouter adds the custom service port.

### Deleting a Custom Service Port

1. Open QuRouter.
2. Go to **Service Port Management**.
3. Identify a custom service port.
4. .  
Click .  
A confirmation message appears.
5. Click **Yes**.

QuRouter deletes the custom service port.


### DDNS Settings

Dynamic DNS Service (DDNS) allows internet access to the router using a domain name instead of an IP address. This ensures that the router is accessible even if the client ISP changes the IP assignment.

## Configuring DDNS (My DDNS) Settings

1. Open QuRouter.
2. Go to **DDNS Settings**.
3. Click **DDNS Settings**.  
The **Select WAN Interface** window appears.
4. Select the WAN interface,

Setting	User Action
<b>WAN Interface</b>	Select a configured WAN port.
<b>Static IP</b>	Manually assign a fixed IP address.
<b>Obtain an Automatic DHCP IP Address</b>	If the network supports DHCP, the adapter automatically obtains the IP address and network settings.

5. Click **OK**.  
QuRouter updated the DDNS settings.
6. .  
Click .

QuRouter enables the DDNS service.

## Modifying the DDNS Domain Name

You can edit the DDNS domain name to change the address used to access the device.

1. Open QuRouter.
2. Go to **DDNS Settings**.
3. Click **Edit Domain Name**.  
The **Edit Device Name** window appears.
4. Enter the DDNS domain name.



### Note

The myQNAPcloud domain name must be between 3 and 15 characters and can contain letters (A-Z, a-z), and numbers (0-9).

5. Click **OK**.


QuRouter updates the DDNS domain name.

## 8. Security Settings

### Firewall


Firewall rules allow you to control information flow in individual packets and configure permissions according to a defined criterion.


From here you can enable the firewall and manage individual firewall rules.



### Adding a Firewall Rule

1. Go to **NAT/Firewall > Firewall Rule** .
2. Click **Add**.  
The **Add Rule** window appears.
3. Configure the firewall rule settings.



Setting	User Action
<b>Rule Name</b>	Specify a firewall rule name.   <b>Note</b> Requirements: <ul style="list-style-type: none"> <li>• Length: 1–32 characters</li> <li>• Valid characters: A–Z, a–z, 0–9</li> </ul>
<b>Protocol</b>	Specify the IP protocol type for this rule.

Setting	User Action
<b>Source</b>	<p>Specify the connection source for this rule.</p> <ul style="list-style-type: none"> <li>• Selecting <b>Any</b> applies this rule to all connections.</li> <li>• Selecting <b>Define</b> applies this rule to traffic coming from the sources defined for this rule. <ul style="list-style-type: none"> <li>• Selecting <b>None</b> allows you to apply the rule to traffic coming from the client operating system.</li> <li>• Selecting <b>Interface</b> allows you to apply the rule to traffic originating from all the IP addresses from the selected WAN, LAN, or VLAN interface.</li> <li>• Selecting <b>IP</b> allows you to apply the rule to connections from a single IP, a specific subnet, or every IP within a specific range.</li> </ul> </li> </ul>
<b>Destination</b>	<p>Specify the connection destination for this rule.</p> <ul style="list-style-type: none"> <li>• Selecting <b>Any</b> applies this rule to all connections.</li> <li>• Selecting <b>Define</b> applies this rule to traffic directed to all destinations defined for this rule. <ul style="list-style-type: none"> <li>• Selecting <b>IP</b> allows you to apply the rule to connections going to a single IP, a specific subnet, or every IP within a specific range.</li> <li>• Selecting <b>Domain name</b> allows you to apply the rule to traffic going to all the IP address associated with the specified domain name.</li> </ul> </li> </ul>
<b>Port</b>	<p>Specify the IP protocol type for this rule. This field is available only if you select the <b>TCP</b> or <b>UDP</b> protocol.</p> <div data-bbox="422 1182 478 1243" style="display: inline-block; vertical-align: middle;">  </div> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Ports must be between 1 - 65535</li> <li>• This field can have up to 15 ports.</li> <li>• Separate multiple ports with commas (,)</li> <li>• Use hyphens (-) without a space to indicate a port range</li> </ul>
<b>Action</b>	Specify whether this rule allows or blocks matching connections.

4. Click **Save**.

QuRouter creates the firewall rule.

### Configuring a Firewall Rule

1. Go to **NAT/Firewall > Firewall Rule** .
2. Identify a role.
3.  Click  .  
The **Edit Rule** window appears.
4. Configure the firewall rule settings.





For details, see [Adding a Firewall Rule](#).

5. Click **Save**.

QuRouter updates the firewall rule.

## Deleting a Firewall Rule

1. Go to **NAT/Firewall > Firewall Rule**.
2. Identify a firewall rule.
3.  Click . A confirmation message appears.
4. Click **Apply**.

QuRouter deletes the firewall rule.

## Network Address Translation (NAT)

NAT allows private networks that use unregistered IP addresses to connect to the internet. NAT translates private IP addresses in the internal network to public IP addresses before forwarding the packets onto another network.

## Application Layer Gateway (ALG)

The ALG function allows you to implement transparent network translation on certain application layer protocols. NAT ALG supports the following protocols:

- File Transfer Protocol (FTP)
- Point-to-Point Tunneling Protocol (PPTP)
- Session Initiation Protocol (SIP)

You can enable the ALG function on these protocols by enabling the toggle switch located beside the protocol name.


## Port Forwarding

You can configure port forwarding rules that can be used to direct incoming and outgoing traffic on your router to a device connected to your network.

## Adding a Port Forwarding Rule

Before configuring port forwarding rules, ensure you add custom service ports in **Service Port Management**. For details, see [Adding a Custom Service Port](#).



1. Go to **NAT/Firewall > NAT > Port Forwarding**.
2. Click **Add Rule**. The **Add Rule** window appears.
3. Configure the rule settings.

Setting	User Action
<b>WAN service port</b>	Select the custom WAN service port from the drop-down menu.
<b>WAN port</b>	Select the WAN port from the drop-down menu.
<b>Host IP address</b>	Specify the LAN IP address.
<b>LAN service port</b>	Specify a service port number for the host IP address.
<b>Allowed remote IPs</b>	Specify one or more remote IP addresses.  <div style="display: flex; align-items: center;">  <div> <p><b>Note</b> Leaving this field blank allows access from any remote IP address.</p> </div> </div>
<b>Description</b>	Enter a description for the rule.

4. Click **Apply**.



QuRouter adds the port forwarding rule.

### Configuring a Port Forwarding Rule

1. Go to **NAT/Firewall > NAT > Port Forwarding** .
2. Identify a rule to configure.
3.  Click  .  
The **Edit Rule** window appears.
4. Configure port forwarding settings.  
For details, see [Adding a Port Forwarding Rule](#).
5. Click **Apply**.

QuRouter updates the port forwarding rule.

### Deleting a Port Forwarding Rule

1. Go to **NAT > Port Forwarding** .
2. Identify a rule.
3.  Click  .  
A confirmation message appears.
4. Click **Apply**.

QuRouter deletes the rule.

### Demilitarized Zone (DMZ)

A Demarcation Zone or Demilitarized Zone (DMZ) creates a publicly accessible subnetwork behind your firewall. Configuring a DMZ rule allows you to add public services to your WAN without compromising the overall security of your network.



You can configure DMZ rules only on configured WAN interfaces that are not in use by port forwarding rules.

## Configuring DMZ Settings

1. Go to **NAT/Firewall > NAT > Demilitarized Zone (DMZ)**.
2. Identify a DMZ rule.





### Note

- 1GbE WAN port 1 is used as the default interface for the DMZ rule.
- Each configured WAN port is allowed one DMZ rule.

3.



Click .  
The **DMZ Settings** window appears.

4. Specify the subnet IP address for the DMZ rule.
5. Click **Apply**.  
QuRouter applies the settings.
6. .  
Click .  
QuRouter enables the DMZ rule.

## Deleting a DMZ Rule

1. Go to **NAT/Firewall > NAT > Demilitarized Zone (DMZ)**.
2. Identify a DMZ rule.

3.



Click .

QuRouter deletes the DMZ rule.

## Discovery Settings

QuRouter enables you to locate and manage network infrastructure on your domain.



## Configuring Universal Plug and Play (UPnP)


Universal Plug and Play (UPnP) is a networking protocol that enables dynamic port opening for peer-to-peer device communication on the network.



### Important

Enabling UPnP makes the device discoverable on the internet and vulnerable to malware infections. Disable when not in operation.

1. Go to **NAT/Firewall > UPnP**.
2. .  
Click .  
The device enables the UPnP function.

3. Beside WAN interface, click . The **Select WAN Interface** window appears.
4. Select the WAN port.
5. Click **OK**.

QuRouter applies the UPnP settings.



**Tip**

You can view the VLAN-enabled UPnP in **UPnP Service List**. By default, UPnP is enabled on VLAN 1 and the device advertises itself to plug and play devices connected to VLAN 1.

## Parental Controls

QuRouter provides parental control functions to manage content filtering, safe search, and protect connected clients from inappropriate and harmful content. Network administrators can create custom parental control rules to limit internet access, block websites, and assign rules to connected devices.

### Adding a Parental Control Role



1. Go to **Parental Controls**.
2. Click **Add Role**. The **Add Role** window appears.
3. Configure the role settings.

Setting	User Action
<b>Role name</b>	Specify a name for the parental control role.
<b>Enable website filter</b>	Select this option to enable website filtering to prevent users from viewing certain URLs or websites.
<b>Domain Name Filter</b>	Enter an entire domain name or specific URLs. Separate multiple URLs with commas (,).
<b>Safe Search</b>	<p>Enable safe search to filter out explicit content in the following sites:</p> <ul style="list-style-type: none"> <li>• <b>YouTube</b></li> </ul> <div style="border-left: 2px solid #0070C0; padding-left: 10px; margin-left: 20px;"> <p><b>Note</b> You can select from the following restriction modes:</p> <ul style="list-style-type: none"> <li>• <b>Restricted:</b> Completely block potentially mature and violent content.</li> <li>• <b>Medium:</b> Partially allow explicit and adult-oriented content.</li> </ul> </div> <ul style="list-style-type: none"> <li>• <b>Google</b></li> <li>• <b>Bing</b></li> </ul>

4. Click **Apply**.



QuRouter creates the parental control role.

## Configuring a Parental Control Role

1. Go to **Parental Controls**.
2. Identify a role.
3.  Click  .  
The **Edit Role** window appears.
4. Configure the parental role settings.  
For details, see [Adding a Parental Control Role](#).
5. Click **Apply**.

QuRouter updates the parental control role.

## Deleting a Parental Control Role

1. Go to **Parental Controls**.
2. Identify a role.
3.  Click  .  
A confirmation message appears.
4. Click **Apply**.

QuRouter deletes the role.

## Adding a Device to a Parental Control Role





### Note

You cannot assign a single device to more than one role at a time.

1. Go to **Parental Controls**.
2. Identify a role to add to a device.
3. Click **Add Device**.  
The **Add Device** window appears.
4. Select a wireless device from the list.
5. Click **Add**.

QuRouter adds the device to the parental control role.

## Deleting a Device from a Parental Control Role

1. Go to **Parental Controls**.
2. Identify the device to delete.
3.  Click  .

A confirmation message appears.

4. Click **OK**.

QuRouter removes the device from the parental control role.

## Quality of Service (QoS)


Quality of service (QoS) improves network traffic shaping by classifying and prioritizing different network devices and packets.

To configure QoS settings, you must add the device to the QuWAN service and configure the settings using QuWAN Orchestrator.

### Configuring QoS Settings on QuWAN Orchestrator

1. Open QuRouter.
2. Go to **QuWAN > Quality of Service (QoS)**.
3. Click **QoS Configuration on QuWAN Orchestrator**.
4. Log in to QuWAN Orchestrator.
5. Go to **QuWAN Device**.
6. Select the region and your device.
7. Click **Quality of Service**.
8. Under **Quality of Service**, click **Add**.  
The **Add Quality of Service Rule** window appears.
9. Specify a rule name.
10. Configure rule settings.

Setting	User Action
<b>Source</b>	Specify the connection source for the rule. <ul style="list-style-type: none"> <li>• Selecting <b>Any</b> applies this rule to all connections.</li> <li>• Selecting <b>Define</b> applies this rule to traffic coming from the sources defined for this rule.                             <ul style="list-style-type: none"> <li>• Selecting <b>None</b> allows you to apply the rule to traffic coming from the client operating system. Specify the client OS from the drop-down list.</li> <li>• Selecting <b>IP</b> allows you to apply the rule to connections from a single IP, a specific subnet, or every IP within a specific range.</li> </ul> </li> </ul>

Setting	User Action
<b>Destination</b>	<p>Specify the connection destination for this rule.</p> <ul style="list-style-type: none"> <li>• Selecting <b>Any</b> applies this rule to all connections.</li> <li>• Selecting <b>Define</b> applies this rule to traffic directed to all destinations defined for this rule. <ul style="list-style-type: none"> <li>• Selecting <b>None</b> allows you to apply the rule to traffic going to the client operating system. Specify the client OS from the drop-down list.</li> <li>• Selecting <b>IP</b> allows you to apply the rule to connections from a single IP, a specific subnet, or every IP within a specific range.</li> <li>• Selecting <b>Domain name</b> applies the rule to a specific domain name.</li> </ul> </li> </ul>
<b>Protocol</b>	Specify the network transport protocol for the rule.
<b>Port</b>	<p>Specify the service port number. This field is only available if the TCP or UDP protocol is selected.</p> <div data-bbox="422 857 478 913" style="display: inline-block; vertical-align: middle;"></div> <div data-bbox="502 857 550 891" style="display: inline-block; vertical-align: middle;"><b>Tip</b></div> <ul style="list-style-type: none"> <li>• Specify a port number between 1 and 65535.</li> <li>• Enter up to 15 ports.</li> <li>• Separate multiple ports with commas (,).</li> <li>• Use hyphens (-) without spaces to indicate a port range.</li> </ul>
<b>Application</b>	<p>Specify whether this rule allows or blocks specific applications or application categories.</p> <ul style="list-style-type: none"> <li>• Selecting <b>Any</b> applies this rule to all applications and application categories.</li> <li>• Selecting <b>Define</b> applies this rule to traffic directed to all applications and categories defined for this rule.</li> </ul>
<b>Action</b>	<ul style="list-style-type: none"> <li>• Service class: Specify the service class priority from the drop-down list.</li> <li>• Network steering: Select the band steering method to steer traffic based on the QoS markings on the packets. <ul style="list-style-type: none"> <li>• <b>Auto:</b> QuWAN Orchestrator automatically detects the optimal transmission path for steering traffic.</li> <li>• <b>Direct:</b> Manually select the WAN port to steer traffic.</li> </ul> </li> </ul>

**11. Click Create.**

QuWAN Orchestrator adds the QoS rule.

## 9. Support and Other Resources

### Support and Other Resources

QNAP provides the following resources:

Resource	URL
Documentation	<a href="https://docs.qnap.com">https://docs.qnap.com</a>
Service Portal	<a href="https://service.qnap.com">https://service.qnap.com</a>
Downloads	<a href="https://download.qnap.com">https://download.qnap.com</a>
Community Forum	<a href="https://forum.qnap.com">https://forum.qnap.com</a>



## 10. Glossary

### **myQNAPcloud**

Provides various remote access services such as DDNS and myQNAPcloud Link

### **QNAP ID**

User account that enables you to use myQNAPcloud remote access and other QNAP services

### **Qfinder Pro**

QNAP utility that lets you locate and access QNAP devices in your local area network

### **QuRouter**

The QNAP web management interface that allows you to view and configure QNAP routers

### **QuWAN**

QNAP SD-WAN management system

### **QuWAN Orchestrator**

QNAP centralized management cloud platform for SD-WAN infrastructure

## 11. Notices

This chapter provides information about warranty, disclaimers, licensing, and federal regulations.

### Limited Warranty

QNAP offers limited warranty service on our products. Your QNAP-branded hardware product is warranted against defects in materials and workmanship for a period of one (1) year or more from the date printed on the invoice. ("Warranty Period"). Please review your statutory rights at [www.qnap.com/warranty](http://www.qnap.com/warranty), which may be amended from time to time by QNAP in its discretion.

### Disclaimer

Information in this document is provided in connection with products of QNAP Systems, Inc. (the "QNAP"). No license, express or implied, by estoppels or otherwise, to any intellectual property rights is granted by this document. Except as provided in QNAP's terms and conditions of sale for such products, QNAP assumes no liability whatsoever, and QNAP disclaims any express or implied warranty, relating to sale and/or use of QNAP products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right.

QNAP products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

In no event shall QNAP's liability exceed the price paid for the product from direct, indirect, special, incidental, or consequential damages resulting from the use of the product, its accompanying software, or its documentation. QNAP makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. QNAP reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

Back up the system periodically to avoid any potential data loss is recommended. QNAP disclaims any responsibility of all sorts of data loss or recovery.

Should you return any components of the package of QNAP products for refund or maintenance, make sure they are carefully packed for shipping. Any form of damages due to improper packaging will not be compensated.

All the features, functionality, and other product specifications are subject to change without prior notice or obligation. Information contained herein is subject to change without notice.

All the features, functionality, and other product specifications are subject to change without prior notice or obligation. Information contained herein is subject to change without notice.

Further, the ® or ™ symbols are not used in the text.

### CE Notice



This QNAP device complies with CE Compliance Class B.

## FCC Notice

### FCC Class B Notice



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.



#### Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



#### Important

Any modifications made to this device that are not approved by QNAP Systems, Inc. may void the authority granted to the user by the FCC to operate this equipment.

## Radio Equipment Directive (RED) 2014/53/EU Article 10



RED 2014/53/EU requires that for products which could potentially have an issue with a non-harmonized frequency in a specific EU country, the product documentation must list the restrictions, and the packaging must carry a label reflecting that country's code.

This QNAP router complies with RED 2014/53/EU article 10.

## EU RoHS statement

This equipment complies with the European Union RoHS Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment. The directive applies to the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic equipment.

## ISED Compliance Statement

Industry Canada has been renamed Innovation, Science, and Economic Development Canada (ISED) following the issue of RSP-100 Issue 11 and DC-01 Issue 06. Equipment certifications previously issued by Industry Canada remain valid and do not require updating. Meaning you may see the names used interchangeably in documentation. The following statement is applicable to ASiR-pRRH which has Innovation, Science and Economic Development (ISED) approval: This device complies with ICES-003 of Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

## Radiation Exposure Statement

This product complies with the IC radiation exposure limits set for an uncontrolled environment. To comply with RSS 102 RF exposure compliance requirements, a separation distance of at least 27 cm must be maintained between the antenna of this device and all persons. The device for the band 5150-5350 MHz is only for indoor usage to reduce potential harmful interference to co-channel mobile satellite systems.

## UKCA Notice



This device complies with the UKCA requirements for products sold in Great Britain.